5. DataFrame Analysis

Questions

- What are some common attributes of Pandas DataFrame s?
- What are some common methods of Pandas DataFrame s?
- How can you do arithmetic between two Pandas columns?

Objectives

- Learn how to access DataFrame attributes.
- Learn how to get statistics on a loaded DataFrame.
- Learn how to sum two Pandas DataFrame columns together.

DataFrame Attributes

- DataFrame are python objects
 - They have access to dozens of attributes and methods that can be used to inspect, wrangle or analyze the data.

Attribute	Description						
shape	Returns a tuple representing the dimensionality of the DataFrame.						
size	Returns an int representing the number of elements in this object.						
dtypes	Returns the data types in the DataFrame.						
columns	Returns a Series of the header names from the DataFrame						

- See Pandas doc for list of attributes and methods
- In Jupyter (and most other IDEs), you can use `tab` to see which attributes and objects are available on an object
- use `help` function or the `?` character to get more details about a method or attribute

```
In [19]:
import pandas as pd
    df = pd.read_csv("data/types_dataframe.csv")
    df.shape
```

Out[19]: (8, 7)

Inspecting Data Types

- DataFrame types determine methods that can be used on the data
 - You can compute the mean of a numeric value but not an Object column (i.e. words).
 - Common friction point in data analysis (compute average price)
- The dtypes attribute is an attribute that provides access to the type of each column
 - Note the column date mmddyy

	Sample ID	date mmddyy	press dbar	temp ITS-90	csal PSS-78	coxy umol/kg	ph
0	Sample-1	40610	239.8	18.9625	35.0636	NaN	7.951
1	Sample-2	40610	280.7	16.1095	34.6103	192.3	NaN
2	Sample-3	40610	320.1	12.9729	34.2475	190.8	NaN
3	Sample-4	40610	341.3	11.9665	34.1884	191.3	7.780
4	Sample-5	40610	360.1	11.3636	34.1709	203.5	NaN
5	Sample-6	40610	385.0	10.4636	34.1083	193.7	NaN
6	Sample-7	40610	443.7	8.5897	34.0567	156.5	NaN
7	Sample-8	40610	497.8	7.1464	34.0424	110.7	7.496

```
In [6]: df.dtypes
Out[6]:
        Sample ID
                          object
         date mmddyy
                           int64
         press dbar
                         float64
         temp ITS-90
                         float64
         csal PSS-78
                         float64
         coxy umol/kg
                         float64
         ph
                         float64
```

dtype: object

Data Types

• Pandas data types:

Python Type	Equivalent Pandas Type	Description
string	object	Columns contain partially or completely made up from strings
int	int64	Columns with numeric (integer) values. The 64 here refers to size of the memory space allocated to this type (precision)
float	float64	Columns with floating points numbers (numbers with decimal points)
bool	bool	True/False values
datetime	datetime	Date and/or time values

Data Types Inference

- Pandas attempts to figure out the column's data type when reading in the data.
 - Type is inferred purely based on the data format.
- Datatypes can be specified when loading the data or after loading the data.
- For Example, we can convert the date mmddyy column into a new Series with the datetime type.
 - use the to_datetime function with the data and the date format ('%m%d%y' in this case) as inputs.
 - datetime uses python date formats

```
In [9]: # Add the data a as new column (same syntax as adding to a collection i
        # and remove old column
        df["date"] = pd.to datetime(df['date mmddyy'], format='%m%d%y')
        df = df.drop(columns=["date mmddyy"])
        df.dtypes
Out[9]:
         Sample ID
                                object
                                float64
         press dbar
         temp ITS-90
                                float64
         csal PSS-78
                                float64
         coxy umol/kg
                                float64
         ph
                                float64
         date
                         datetime64[ns]
         dtype: object
```

In [10]: df

Out[10]:

_		Sample ID	press dbar	temp ITS- 90	csal PSS- 78	coxy umol/kg	ph	date
	0	Sample-1	239.8	18.9625	35.0636	NaN	7.951	2010-04- 06
	1	Sample-2	280.7	16.1095	34.6103	192.3	NaN	2010-04- 06
	2	Sample-3	320.1	12.9729	34.2475	190.8	NaN	2010-04- 06
	3	Sample-4	341.3	11.9665	34.1884	191.3	7.780	2010-04- 06
	4	Sample-5	360.1	11.3636	34.1709	203.5	NaN	2010-04- 06
	5	Sample-6	385.0	10.4636	34.1083	193.7	NaN	2010-04- 06
_	6	Sample-7	443.7	8.5897	34.0567	156.5	NaN	2010-04- 06
	7	Sample-8	497.8	7.1464	34.0424	110.7	7.496	2010-04- 06

DataFrame Methods

- DataFrame and Series (e.g., single column) have access to a variety of built-in methods
 - Accessible through the notation some_var_name.method_name()

Method	Description	
head()	Return the first $n=5$ rows by default. The value of n can be changed.	
tail()	Return the last $n=5$ rows by default. The value of n can be changed.	
<pre>min(), max()</pre>	Computes the numeric or alphanumeric min, max in a Series or DataFrame.	
<pre>sum(), mean(), std(), var()</pre>	Computes the sum, mean, standard deviation, and variance in a Series or DataFrame.	
nlargest()	Return the first n rows of the Series or DataFrame, ordered by the specified columns in descending order.	
count()	Returns the number of non-NaN values in a Series or DataFrame.	
<pre>value_counts()</pre>	Returns the frequency for each value in the Series .	
describe()	Computes column-wise statistics.	

In [8]: df.mean(numeric_only=True)

/var/folders/51/gk6s2xx10qs0mkq4 9 vyp3h0000qn/T/ipykernel 9653 7/3698961737.py:1: FutureWarning: The default value of numeric only in DataFrame.mean is deprecated. In a future version, it w ill default to False. In addition, specifying 'numeric only=Non e' is deprecated. Select only valid columns or specify the valu e of numeric only to silence this warning. df.mean()

Out[8]: date mmddyy 40610.000000 press dbar 358.562500 temp ITS-90 12.196838 csal PSS-78 34.311013 coxy umol/kg 176.971429 7.742333 ph dtype: float64

```
In [9]: df.mean(numeric_only=True)
```

Out[9]:	date mmddyy	40610.000000
	press dbar	358.562500
	temp ITS-90	12.196838
	ccal DCC_78	3/1 311013

coxy umol/kg 176.971429

ph 7.742333

dtype: float64

3 341.3 4 360.1 5 385.0 6 443.7 7 497.8 Name: press dbar, dtype: float64

```
In [11]: # Accessing a single column
df['press dbar'].mean()
```

Out[11]: 358.5625

describe() Method

- The describe() method provides a range of descriptive statistics of a dataframe
- Statistics to summarize the central tendency, dispersion, and shape of a dataset's distribution
- By default, uses only numeric columns.
 - change behavior using the include='all' param.

In [17]: df

Out[17]:

	Sample ID	date mmddyy	press dbar	temp ITS- 90	csal PSS- 78	coxy umol/kg	ph
0	Sample-1	40610	239.8	18.9625	35.0636	NaN	7.951
1	Sample- 2	40610	280.7	16.1095	34.6103	192.3	NaN
2	Sample- 3	40610	320.1	12.9729	34.2475	190.8	NaN
3	Sample- 4	40610	341.3	11.9665	34.1884	191.3	7.780
4	Sample- 5	40610	360.1	11.3636	34.1709	203.5	NaN
5	Sample- 6	40610	385.0	10.4636	34.1083	193.7	NaN
6	Sample-7	40610	443.7	8.5897	34.0567	156.5	NaN
7	Sample- 8	40610	497.8	7.1464	34.0424	110.7	7.496

In [16]: df.describe(include='all', datetime_is_numeric=True)

Out[16]:

	Sample ID	date mmddyy	press dbar	temp ITS- 90	csal PSS- 78	coxy umol/kg	
count	8	8.0	8.000000	8.000000	8.000000	7.000000	3.0
unique	8	NaN	NaN	NaN	NaN	NaN	
top	Sample- 1	NaN	NaN	NaN	NaN	NaN	
freq	1	NaN	NaN	NaN	NaN	NaN	
mean	NaN	40610.0	358.562500	12.196838	34.311013	176.971429	7.7
std	NaN	0.0	83.905762	3.853666	0.353064	32.726376	0.2
min	NaN	40610.0	239.800000	7.146400	34.042400	110.700000	7.4
25%	NaN	40610.0	310.250000	9.995125	34.095400	173.650000	7.6
50%	NaN	40610.0	350.700000	11.665050	34.179650	191.300000	7.7
75%	NaN	40610.0	399.675000	13.757050	34.338200	193.000000	7.8
max	NaN	40610.0	497.800000	18.962500	35.063600	203.500000	7.9

Key points

- DataFrame's and Series have a plethora of attributes and variables to access data
 - See Pandas doc , or use tab to explore.
- Use .dtypes to get the types of each column in a DataFrame.
- To get general statistics on the DataFrame you can use the describe method.

Break

We will take a 10-minute break before we move on to the final two lessons